

## Vägglucka

# LUX PROFFS

### **SWE** Monteringsanvisning

Kontrollera först leveransens innehåll:  
Lucka enligt följesedel  
Montagepåse

Innehåll i montagepåse:  
Plastlock (antal enligt storlek)  
Monteringsanvisning

För montage behövs:  
Infästningsmaterial anpassad till väggtyp  
Vattenpass  
Slagbormaskin/Bormaskin  
Skruvdragare/Skruvmejsel  
Sextkantnyckel, 12 mm (för hylsor)  
Sextkantnyckel, 3 mm (för justering av gångjärn)

### Montering:

1. Kontrollera att öppningen är 15-20mm större än luckans karmyttermått.
2. Isolera karmen. Anpassa isoleringen efter hållmått.
3. Kontrollera att luckan är i våg.
4. Centra karmen i öppningen genom att skruva ut hylsorna med sextkantnyckel. Kontrollera att det är i våg och lod. OBS! Ta inte för givet att väggarna är i lod. Dra inte hylsorna för hårt så att karmsidorna bågna.
5. Borra hålen för infästningen uppe och nere på gångjärnsidan och skruva fast karmen. Kontrollera att karmen fortfarande är i lod.
6. Borra hålen för infästning på låssidan och skruva fast karmen. Borra och skruva fast karmen i resterande hål. Vid behov justeras karmen i sidled med hjälp av hylsorna.
7. Montera plastlocken över hålen i karmen.
8. Dreva mellan karm och vägg med obrännbart material och foga alternativt montera täckplåtar/foder.

## Wall hatch

# LUX PROFFS

### **GBR** Assembly instructions

Check the content of the package first:  
Wall hatch according to the waybill  
Assembly package

Assembly package includes:  
Plastic caps (the number depends on the hatch size)  
Assembly instructions

The following is needed for assembly:  
Fitting materials depending on the kind of wall  
Carpenter's level  
Hammer drill / Drilling machine  
Cordless screwdriver / screwdriver  
Hex nut wrench, 12 mm (for bush bolts)  
Hex nut wrench, 3 mm (for adjustment of hinges)

### Assembly:

1. Check that the hole in the wall is 15-20 mm bigger than casing's outer size.
2. Lay the hatch on the floor, and ensure the correct thickness of packing material is positioned around the frame to match the hole in the wall.
3. Make sure that the hatch is square.
4. Place the hatch in the hole symmetrically by screwing the bush bolts with the hex nut wrench. Check that the hatch is both square and plumb. NOTE! Do not take for granted that the walls are plumb. Do not screw the bush bolts too hard so that the casing is buckling.
5. Drill the holes up and down on the hinge side and screw tight the casing. Make sure that the casing is still plumb.
6. Drill the holes on the lock side and screw tight the casing. Drill the rest of the holes and screw tight the casing. If needed, adjust the casing sidewise with the bush bolts.
7. Attach the plastic caps on the holes of the casing.
8. Caulk between the casing and the wall with a non-combustible material.